

# INSTAL INSTALLATIONSKANALER



## VÄGGRAM

|                |           |
|----------------|-----------|
| INSTAL LVK 108 | 11 714 12 |
| INSTAL LVK 144 | 11 714 13 |
| INSTAL LVK 170 | 11 714 14 |
| INSTAL LVK 210 | 11 714 15 |

## LOCK

|               |           |
|---------------|-----------|
| INSTAL K80 M  | 11 713 99 |
| INSTAL K80 AD | 11 713 98 |

## LOCK

|               |           |
|---------------|-----------|
| INSTAL K45 M  | 11 713 97 |
| INSTAL K45 AD | 11 713 96 |

## LJUDISOLERING

|               |           |
|---------------|-----------|
| INSTAL LIS-48 | 11 709 65 |
| INSTAL LIS-80 | 11 709 66 |

## ANSLUTNINGSKRAGE

|               |           |
|---------------|-----------|
| INSTAL LK 108 | 11 714 16 |
| INSTAL LK 144 | 11 714 17 |
| INSTAL LK 170 | 11 714 18 |
| INSTAL LK 210 | 11 714 19 |

## SKILJEVÄGG

|            |           |
|------------|-----------|
| INSTAL VS  | 11 714 10 |
| INSTAL VS2 | 11 714 11 |

## SKARVSTYCKE

|          |           |
|----------|-----------|
| INSTAL J | 11 714 00 |
|----------|-----------|

## APPARATDOSA

|           |           |
|-----------|-----------|
| INSTAL KR | 11 714 20 |
| INSTAL PK | 11 714 21 |

## ÄNDSTYCKE

|                    |           |
|--------------------|-----------|
| INSTAL P 108 M     | 11 713 90 |
| INSTAL P 108 AD    | 11 713 86 |
| INSTAL P 144 M     | 11 713 91 |
| INSTAL P 144 AD    | 11 713 87 |
| INSTAL P 170 M     | 11 713 92 |
| INSTAL P 170 AD    | 11 713 88 |
| INSTAL P 210 M     | 11 713 93 |
| INSTAL P 210 AD    | 11 713 89 |
| INSTAL P 170/90 M  | 11 713 95 |
| INSTAL P 170/90 AD | 11 713 94 |

## INSTALLATIONSKANAL

|                    |           |
|--------------------|-----------|
| INSTAL 108 M       | 11 713 67 |
| INSTAL 108 AD      | 11 713 60 |
| INSTAL 144 M       | 11 713 68 |
| INSTAL 144 AD      | 11 713 61 |
| INSTAL 170-1 M     | 11 713 69 |
| INSTAL 170-1 AD    | 11 713 62 |
| INSTAL 170-2 M     | 11 713 70 |
| INSTAL 170-2 AD    | 11 713 63 |
| INSTAL 210-2 M     | 11 713 71 |
| INSTAL 210-2 AD    | 11 713 64 |
| INSTAL 170-2/90 M  | 11 713 73 |
| INSTAL 170-2/90 AD | 11 713 66 |

## MATARKANAL

|                    |           |
|--------------------|-----------|
| INSTAL FT 100 M    | 11 713 00 |
| INSTAL FT 100 AD   | 11 713 01 |
| INSTAL FT 150 M    | 11 713 02 |
| INSTAL FT 150 AD   | 11 713 03 |
| INSTAL FT 150-4 M  | 11 713 04 |
| INSTAL FT 150-4 AD | 11 713 05 |
| INSTAL FT 180 M    | 11 713 06 |
| INSTAL FT 180 AD   | 11 713 07 |

## VENTILATIONSGALLER

|              |           |
|--------------|-----------|
| INSTAL PS M  | 11 714 02 |
| INSTAL PS AD | 11 714 01 |

## VÄGGKONSOL

|               |           |
|---------------|-----------|
| INSTAL SK 20  | 11 714 05 |
| INSTAL SK 40  | 11 714 06 |
| INSTAL SK 75  | 11 714 07 |
| INSTAL SK 100 | 11 714 08 |
| INSTAL SK 125 | 11 714 09 |

## JUSTERVINKEL FÖR VÄGGKONSOL

|           |           |
|-----------|-----------|
| INSTAL SL | 11 714 04 |
|-----------|-----------|